



1335 Lakeside Dr. Unit 7 - Romeoville, IL 60446 - P: 630-679-1300 - F: 630-679-1356
 info@laserproductsus.com - www.LaserProductsUS.com

For the LT-55 XL software to communicate with Moraware, the templator needs to have access to perform API Requests. If the user is an admin, they should have it by default. However if they do not, you can give them the correct permissions by performing the following actions.

1. On an admin account, click **Admin** in the top menu bar.
2. Click **Roles** and then click **New Role**.
3. Enter a **Role Name** and **Description**.

4. Click **Select** next to Users and choose the templator that you need to give access to and click **OK**.

5. Scroll down and next to API Requests, click the check box under the Full Control Column and click **OK**.

Administration						
	Full Control	Create	Read	Update	Delete	Execute
Shared Saved Views and Reports	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Account Settings	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Salespeople	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Job Settings	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Assignees	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Calendar Settings	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
System Settings	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Backup Database	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Restore Database	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Install License	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Import Data	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
API Requests	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>

6. In the LT-55 XL program click **Edit / Options** and scroll to the bottom of the General Setting tab.
7. Look for the Job Tracker Settings

Job Tracker Settings

API URL
(https://<xyz>.moraware.net/<xyz>/api.aspx):

User Name:

Password:

8. In the **API URL** box enter the web address that you use to log in on line through your web browser but changed to match the example directly below it.
 - a. NOTE: This will be the exact same address as through the web browser only the it should read **api.aspx** in instead of **d.aspx** like it does in the browser after the final slash.
9. Enter your Username and Password and then press OK.